



0.1mm-0.15mm PVC Free Peel And Stick Wallpaper High Gloss Soft Touch

Our Product Introduction

Basic Information

- Place of Origin: Foshan, China
- Brand Name: Realsun Deco
- Model Number: 0011
- Minimum Order Quantity: 3000m
- Price: USD 0.7/m~USD 5/m, negotiate
- Packaging Details: 50m/roll, one roll in one carton packing
- Delivery Time: 15-20 days
- Payment Terms: L/C, T/T, Western Union
- Supply Ability: 500000m/month



Product Specification

- Material: PVC
- Thickness: 0.1mm-0.15mm
- Liner Paper: 80GSM, 100GSM, 120GSM
- Size: 122cm*50m/roll, 60cm*10m/roll
- Design: Wood Grain, Marble, Brick, Flower, Stone And So On
- Surface: Matt, Embosse, High Gloss, Soft Touch
- Application: Furniture, Kitchen Cabinet, Door, Profile, Wall And So On
- Service: OEM, ODM
- Highlight: 0.15mm PVC Peel And Stick Wallpaper,
0.1mm PVC Peel And Stick Wallpaper

Product Description

Self Adhesive Peel and stick PVC Wallpaper

Detail Description

1. **Material:** The main component of the self-adhesive pvc wallpaper is polyvinyl chloride, a synthetic plastic with a reputation for toughness and adaptability.
2. **Adhesive Backing:** We cover the back of the liner paper and the pvc film with a coat of pressure-sensitive adhesive. Remove the lining paper before applying. The glue is made to firmly adhere to many different types of surfaces, such as wood, metal, plastic, and glass.
3. **Thickness:** We offer several thicknesses for our self-adhesive vinyl wallpaper. The thickness you select will rely on the durability requirements and your particular application.
4. **Finish:** There are several different finishes for the self-adhesive vinyl wallpaper, such as glossy, matte, satin, and textured finishes. The look and feel of can be influenced by the finish selection.
5. **Colors and patterns:** A variety of colors and patterns, including wood grain, marble, brick, and other designs, are available for our self-adhesive film.

Specification

Thickness	0.1mm-0.12mm
Width	1220mm, 600mm
Length	50m/roll, 10m/roll
Design	Wood grain, Solid color, Marble, Brick and so on
Surface treatment	Matt, Super matt, embossed, high gloss, soft touch
Service	OEM, ODM

Installation

CONSTRUCTION PROCEDURE



1. Preparation Tool:

We need to prepare a pair of scissors, tape measure, utility knives, rags and scrapers

2. Clean the wall

Clean walls, slightly wipe the wall with damp cloth, remove the dust and impurities on the wall so that the wall is smooth, dry, solid, no bump.



3. Measure the wall size

Measure the wall size in order to reduce the error when you cut the wallpaper.

4. Cutting wallpaper (When cutting, keep the edge straight)
According to your measure of the wall size to cut wallpaper, Please noted that the length of wallpaper should be reserved 5CM more than the height of the wall to prepare trimming.



5. Torn wallpaper

Wallpaper ripped up the back corner of the film.

6. Use the scraper

Use the scraper lightly to calibrate the wallpaper from top to bottom, from the middle to the sides. Expel the air bubbles to make the wallpaper stick on the wall smooth and tight.



7. Obstruction

If the wall with the switch or other obstruction, you can cut the wallpaper around the shape of the switch with knife.

8. Cleaning

Use the cloth to clean and press the wallpaper surface after you stick it.



Packing Detail



Realsun Foshan Realsun Decorative Material Co., Ltd.

+8613790066054

sale1@realsundeco.com

realsundeco.com

Room 706, Build 1, No 121 North of Lingnan Avenue, Foshan, China